

001  
**1**

002  
**2**



003  
**3**

004  
**4**



005  
**5**

006  
**6**



007  
**7**

008  
**8**



009  
**9**

010  
**10**



011  
**11**









012  
**12**

033  
MENU  
+

034  
MENU  
-


053  
Start

054  
Stop





037  
+

038  
-







039  
FAST

040  
SLOW





061  
L

062  
R



043  
ON

044  
OFF



083  
SPEED  
+

084  
SPEED  
-

103  
↑  
OP

104  
↓  
NEER



105  
↙  
IN






106  
↖  
UIT

047  
IN

048  
OUT

067  
BAR  
+

068  
BAR  
-


















































051  
CLOSE


052  
OPEN

071  
MENU

072  
EXIT







001  
**1**

003  
**3**

005  
**5**

007  
**7**

009  
**9**

011  
**11**

002  
**2**

004  
**4**

006  
**6**

008  
**8**

010  
**10**

012  
**12**

013

015

017

019

021

014

016

018

020

022

023

025

027

029

031

024

026

028

030

032

033  
**MENU**  
+

034  
**MENU**  
-

035

036

037  
**+**

038  
**-**

039  
**FAST**

040  
**SLOW**

041

042

043  
**ON**

044  
**OFF**

045

046

047  
**IN**

048  
**OUT**

049

050

051  
**CLOSE**

052  
**OPEN**

053  
**Start**

054  
**Stop**

055  
**I**

056  
**O**

057

058

059

060

061  
**L**

062  
**R**

063

064

065

066

067  
**BAR**  
+

068  
**BAR**  
-

069

070

071  
**MENU**

072  
**EXIT**

073

074

075

076

077

078

079

080

081

082

083  
**SPEED**  
+

084  
**SPEED**  
-

085

086

087

088

089

090

091

092

093

094

095

096

097

098

099

100

101  
**L**

102  
**R**

103  
**UP**

104  
**NEER**

105  
**IN**

106  
**UIT**

107

108

109

110

111

112

